

2nd STOREY FLOOR PENETRATION KIT INSTALLATION INSTRUCTIONS

1. Locate wood burner in desired position with prescribed clearances from walls (see heater installation clearances).
2. Locate centre of flue position on ceiling with plumb-bob or with laser. Mark position and drill pilot hole.
3. Cut out ceiling and floor 205mm x 205mm square above pilot hole.
Note: If structural timbers are to be disturbed, boxing out and re-strengthening may be required
4. With the Floor Mount Bracket slipped over the Outer Liner, lower assembly into cut-out and locate Inner Liner such that it protrudes **25mm below ceiling**.
5. Mark the bracket location against the Outer Liner. Remove assembly from cut-out then fix bracket to Liner in four places with rivets.
6. Insert Liner/Bracket assembly into cut-out and fix to floor through bracket flange.
7. Trim Outer Liner down 50-60mm above floor for Perforated Flue Shield mounting.
8. Lower Floor Plate over Outer Liner and fix to floor using ceramic spacers and the 4 screws provided.
9. Perforated Flue Shields may now be fitted to the protruding section of the Outer Liner.
10. Fit Ceiling Tile once suitable lengths of flue have been positioned to centralise ceiling tile.

